

## **Hardware Reference and Installation Manual**

for the

**1 Gbit/s Copper Medium**

and




**2 Gbit/s Fibre Medium**

**Fibre Channel Adapter**

<b>C<sup>2</sup>I<sup>2</sup> Document No.</b>	CCII/FC/6-MAN/003
<b>Document Issue</b>	1.3
<b>Issue Date</b>	2009-08-20
<b>Print Date</b>	2009-08-21
<b>File Name</b>	P:\Fibrechn\TECH\MAN\CFCMAN03.WPD
<b>Distribution List No.</b>	DN 0501

© C<sup>2</sup>I<sup>2</sup> Systems *The copyright of this document is the property of C<sup>2</sup>I<sup>2</sup> Systems. The document is issued for the sole purpose for which it is supplied, on the express terms that it may not be copied in whole or part, used by or disclosed to others except as authorised in writing by C<sup>2</sup>I<sup>2</sup> Systems.*

## Signature Sheet

Name	Signature	Date
Completed by		2009-08-21
pp X. Keuger	Project Engineer Board Level Products C <sup>2</sup> I <sup>2</sup> Systems	
Accepted by		2009-08-27
L. D. E. Wmm	Project Manager Board Level Products C <sup>2</sup> I <sup>2</sup> Systems	
Accepted by		2009-08-21
X Keuger	Quality Assurance C <sup>2</sup> I <sup>2</sup> Systems	

## Signature Sheet

Name	Signature	Date
Completed by		
	Project Engineer Board Level Products C <sup>2</sup> I <sup>2</sup> Systems	
Accepted by		
	Project Manager Board Level Products C <sup>2</sup> I <sup>2</sup> Systems	
Accepted by		
	Quality Assurance C <sup>2</sup> I <sup>2</sup> Systems	

## Amendment History

Issue	Description	Date	ECP No.
0.1	Initial Draft.	2002-06-21	-
1.0	Base Line Document.	2002-11-01	-
1.1	Fixed up document and corrected LED indicators in Table 2.	2005-07-21	CCII/FC/6-ECP/011
1.2	Updated pictures of CC adapter, added ICD.	2008-03-11	CCII/FC/6-ECP/012
1.3	Improve document naming consistency.	2009-08-20	CCII/FC/6-ECP/017

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page iii of vi

# Contents

<b>1. Scope</b>	<b>1</b>
1.1 Identification	1
1.2 System Overview	1
1.3 Document Overview	1
<b>2. Applicable and Reference Documents</b>	<b>2</b>
2.1 Applicable Documents	2
2.2 Reference Documents	2
<b>3. Functional Description</b>	<b>3</b>
3.1 Hardware Features	3
3.2 Architecture	3
3.2.1 Functional Block Diagram	3
3.2.1.1 PMC Interface	4
3.2.1.2 Serial EEPROM	4
3.2.1.3 Embedded Processor	4
3.2.1.4 SSRAM Memory	5
3.2.1.5 Flash ROM	5
3.2.1.6 Indicators	5
3.3 General Features Description	5
3.3.1 Simple Auto Speed Negotiation	6
3.3.2 Redundant Management	6
3.3.3 Diagnostics	6
3.3.4 Link Controllers	6
3.3.5 High-Speed Link Adaptive Equaliser and Cable Driver on Copper Media	6
<b>4. Connector Pin Assignments</b>	<b>7</b>
4.1 PMC Connector Pinouts	7
4.2 Indicators	7
<b>5. Hardware Installation</b>	<b>8</b>
5.1 The Adapter Kit	8
5.2 Handling Instructions	8
5.3 Installation of the Adapter	8
5.3.1 Step 1 - Prepare the Host Carrier Card (HCC)	9
5.3.2 Step 2 - Install the Adapter onto Host Carrier Card	9
5.3.3 Step 3 - Securing the FC Adapter	11
5.3.3.1 Securing the PMC Adapter	11
5.3.3.2 Securing the CCPMC Adapter	13
<b>6. CCPMC Adapter J4 Pinout Assignment</b>	<b>14</b>
<b>Annexure A</b>	<b>16</b>
Specifications	16

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page iv of vi

## Figures

Figure 1 : Functional Block Diagram of the FC Adapter .....	3
Figure 2 : PMC Connector Layout on FC PMC Adapter .....	7
Figure 3 : LED Layout on CCPMC and PMC Adapters .....	7
Figure 4 : HCC placed on an ESD Workstation .....	9
Figure 5 : Fitting Frontpanel I/O Transceivers Through Frame of the HCC .....	9
Figure 6 : Installing the CCPMC on HCC .....	10
Figure 7 : Correctly Align the PMC Connectors .....	10
Figure 8 : The FC Adapter Installed on HCC with PMC Connectors Connected .....	11
Figure 9 : A PMC Adapter Installed on a HCC .....	11
Figure 10 : Securing the Bezel .....	12
Figure 11 : Securing the Standoffs onto the HCC .....	12
Figure 12 : Secured CCPMC Adapter on the Thermal Conduction Ribs of the HCC .....	13
Figure 13 : CCPMC Adapter Secured at Standoffs from the Reverse Side of HCC .....	13

## Abbreviations and Acronyms

ARM	Advanced RISC Machine
BER	Bit Error Rate
BGA	Ball Grid Array
CC	Conduction-Cooled
CMC	Common Mezzanine Card
CML	Current-Mode Logic
CPU	Central Processing Unit
DRWE	Diagnostic Register Write Enable
EEPROM	Electrically Erasable and Programmable Read Only Memory
ESD	Electrostatic Discharge
FC	Fibre Channel
Gbit/s	Gigabit per second
HCC	Host Carrier Card
IOC	Input / Output Controller
IP	Internet Protocol
LED	Light Emitting Diode
MPI	Message Passing Interface
PAL	Programmable Array Logic
PCI	Peripheral Component Interconnect
PMC	Peripheral Component Interconnect Mezzanine Card
RAM	Random Access Memory
RISC	Reduced Instruction Set Computer
ROM	Read Only Memory
SCSI	Small Computer System Interface
SFF	Small Formfactor
SRAM	Static Random Access Memory
SSRAM	Synchronous Static Random Access Memory
TCP	Transmission Control Protocol
VPD	Vendor Product Data
WWN	World Wide Name

## 1. **Scope**

### 1.1 Identification

This document is the technical reference and installation manual for the Fibre Channel (FC) Peripheral Component Interconnect (PCI) Mezzanine Card (PMC) Adapter.

### 1.2 System Overview

The FC Adapter is a high-performance Dual 2 Gigabit per second (Gbit/s) FC PMC Adapter. It offers a total throughput of 2 Gbit/s (per channel) over fibre and 1 Gbit/s (per channel) over copper. The FC Adapter provides optimal flexibility by simultaneously supporting mass storage and Internet Protocol (IP) protocols on a full duplex 2 Gbit/s FC link.

The FC PMC Adapter uses an embedded Reduced Instruction Set Computer (RISC) processor to handle all the protocol processing and data transfers. This reduces overhead on the host carrier processor, thus allowing higher network data throughput. Data transfers from the FC PMC adapter are controlled independently using single channel Bus Mastering or Scatter Gather Mode over the PMC bus.

### 1.3 Document Overview

The first section in this document will give a functional description and general overview of the hardware features of the FC Adapter. This will be followed by an illustrative layout of the PMC connectors and the Indicators on the PMC adapter. A hardware installation guide is also included in the following section. This section will describe the installation procedure for installing the FC Adapter on a host. The last section in this document will be concerned with the programming interface of the FC Adapter.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 1 of 16



## 2. **Applicable and Reference Documents**

### 2.1 Applicable Documents

- 2.1.1 PCI Special Interest Group, *PCI Local Bus Specification*, Rev. 2.2, dated 1998-12-18.
- 2.1.2 CCII/FC/6-MAN/001, *User Manual for the Fibre Channel Adapter VxWorks Enhanced Network Software Driver*.

### 2.2 Reference Documents

- 2.2.1 CCII/FC/6-MAN/002, *Procedure for Firmware Download and EEPROM Configuration for the C<sup>2</sup>I<sup>2</sup> Systems Fibre Channel PMC Adapter*.
- 2.2.2 IEEE Std 1386.1-2001, *IEEE Standard Physical and Environmental Layers for PCI Mezzanine Cards (PMC)*, dated 2001-06-14.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 2 of 16

### 3. Functional Description

This section provides a technical hardware overview on the FC Adapter.

#### 3.1 Hardware Features

Following is a list of hardware features supported by the FC Adapter :

- Highly integrated full duplex Dual Channel FC Input / Output (I/O) Processor
- Integrated 2 Gbit/s Dual Channel FC serial link
- 64-bit/66 MHz host PMC bus (backward compatible with 32-bit/33 MHz)
- 32-bit embedded Advanced RISC Machine (ARM) RISC processor
- Integrated Bit Error Rate (BER) link testing
- Redundancy Management
- Full simultaneous Target and Initiator operations
- Implements common Message Passing Interface (MPI)
- Firmware stored in Flash, supports up to 2000 concurrent host commands
- Serial Electrically Erasable and Programmable Read Only Memory (EEPROM) for storing configurable factory settings
- High-Speed Link Adaptive Equaliser and Cable Driver on Copper Media
- PCI 2.2 compliant

#### 3.2 Architecture

##### 3.2.1 Functional Block Diagram




Figure 1 : Functional Block Diagram of the FC Adapter

The FC Adapter consists of the following functional elements :

- PMC Interface
- Serial EEPROM
- Embedded Processor
- Synchronous Static Random Access Memory (SSRAM) Memory
- Flash Read Only Memory (ROM)
- Indicators

In the following subsections a brief discussion will follow on each functional element.

#### 3.2.1.1 PMC Interface

The PMC interface allows the FC Adapter to be fitted on any host carrier card conforming to the PMC specification. The Adapter interface to a 64-bit/66 MHz host PCI bus and is backward compatible with a 32-bit/33 MHz PCI bus. The system interface is designed to minimize the amount of time spent on the PCI bus for non-data moving activities such as initialisation, command and error recovery. The interface consists of a PMC bus interface and a number of bus-mode signals. On the FC Adapter the bus-mode signalling is implemented using a Programmable Array Logic (PAL) device, which prevents the card from operating on a non-PMC bus and allows the host to sense the presence of a card in a PMC slot. Refer to the PMC specification [Par. 2.2.2] for a complete description of the PMC interface signals and to the Common Mezzanine Card (CMC) specification [Par. 2.1.1] for information on bus-mode signalling. The Conduction-Cooled (CC) Adapter uses the backplane for I/Os via Pn4 in Figure 2.

#### 3.2.1.2 Serial EEPROM

The serial EEPROM stores nonvolatile data for the embedded processor, such as the World Wide Name (WWN), Vendor Product Data (VPD), and other vendor specific information. The serial EEPROM also stores the configuration settings, specifically to distinguish between the fibre and copper media. The serial EEPROM data is programmed by the firmware. Therefore, the firmware must be downloaded and running before the serial EEPROM can be programmed. The serial EEPROM has an 8 kbit capacity to support full functionality.

The PMC configuration information is also stored in the serial EEPROM device. The information in the EEPROM is loaded by the PMC bridge when the board is reset (either at power-up or during use). The EEPROM must be programmed with valid values before the FC Adapter will be plug-and-play compatible.

Refer to the programming manual [Par. 2.2.1] for more details.

The FC Adapter uses the following default configuration space values :

Offset	Default Value	Description
0x000	0x1000	PCI SIG allocated Vendor Identifier
0x002	0x0622 or 0x0623	Device Identifier
0x010	-	Base Address of FC Adapter assigned by Host

Table 1 : PCI Configuration

#### 3.2.1.3 Embedded Processor

The FC Adapter uses the LSI Logic FC929 32-bit ARM7 RISC processor, hereafter referred to as I/O Controller (IOC), to control all system interface and message transport functionality. This frees the host Central Processing Unit (CPU) for other processing activity and improves overall I/O performance. The IOC and associated firmware have the ability to manage an I/O from start to finish without host intervention. The IOC also manages the message passing interface.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 4 of 16

#### 3.2.1.4 SSRAM Memory

The primary function of this memory is to store data structures used by the IOC to manage exchanges and transmit and receive queues. The SSRAM memory also stores part of the run time image of the IOC firmware, such as initialisation and error recovery code.

The IOC uses a 32-bit non-multiplexed memory bus to access the SSRAM. This memory bus has the capability to address up to 4 MByte of SSRAM. The IOC firmware also supports optional wide parity error detection. This option is configurable, and is specified as a serial EEPROM parameter.

The amount of SSRAM (1 MByte) determines the maximum number of outstanding Request Messages (1024). This roughly equates to the maximum number of outstanding I/O requests pending in the IOC.

#### 3.2.1.5 Flash ROM

The memory controller in the IOC also manages a Flash ROM. The Flash ROM is used to store the firmware for the IOC. In an x86 PC environment the Flash can also store the INT 0x13 boot software.

The Flash ROM is accessed using the upper eight bits of the Memory Interface. Refer to the programming manual [Par. 2.2.1] for procedures regarding the programming of the Flash ROM.

#### 3.2.1.6 Indicators

The FC Adapter provides five indicators to report hardware and software status. The following table describes the use of each indicator :

Indicator	Description
D5	Channel 0 - Active
D4	Channel 0 - Fault
D3	Firmware controlled (Heartbeat)
D2	Channel 1 - Active
D1	Channel 1 - Fault

Table 2 : FC Adapter Indicators

Refer to Figure 3 for the layout of the Indicators on both the PMC and CCPMC Adapters.

During Firmware initialisation, the indicators may also have a secondary function. The indicators may blink out a fault code in case of a hardware - or software failure. These fault codes are listed in the programming manual [Par. 2.2.1].

### 3.3 General Features Description

The FC Adapter is used to connect a host to a High-Speed FC Link. The FCP ANSI standard, FC Private Loop Direct Attach, and Fabric Loop are supported with the use of a sophisticated firmware implementation. Although optimised for a 64-bit PMC interface to communicate with the system CPU(s) and memory, the IOC also supports a 32-bit PMC environment. The system interface to the IOC is designed to minimize the amount of PMC bandwidth required to support I/O requests. A packetised message passing interface is used to reduce the number of single cycle PMC bus cycles. All FC Data traffic on the PMC bus occurs with zero wait bursts across the PMC bus.

The intelligent IOC architecture allows the system to specify I/O commands at the command level. The IOC manages I/Os at the Frame, Sequence and Exchange level. Error detection and I/O retries are also handled by the IOC, allowing the system to offload part of the exception handling work from the system driver.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 5 of 16

### 3.3.1 Simple Auto Speed Negotiation

Backward compatibility with 1 Gbit/s FC devices is maintained through the use of a Simple Auto Speed Negotiation Algorithm. After a power-on, loss of signal, or loss of word synchronization for longer than a certain amount of time, the IOC will perform this operation to determine whether a point-to-point device or all the devices on a loop are either 1 Gbit/s or 2 Gbit/s devices.

### 3.3.2 Redundant Management

The IOC supports two PMC functions and FC Channels, which improves performance and provides a redundant path in highly-availability systems that require failover capabilities. In case of a Link Failure, the IOC architecture allows the OS driver to support automatic failover, without the need for IOC intervention.

### 3.3.3 Diagnostics

The IOC provides the capabilities to do a simplified Link Check Bit Error Rate (BER) test on the link for diagnostic purposes. In a special test mode the controller can transmit and verify a programmed data pattern for link evaluation.

### 3.3.4 Link Controllers

The integrated link controller is FC-AL-2 (Rev. 7.0) compatible and performs all link operations. The controller monitors the Link State and strictly adheres to the Loop Port State Machine ensuring maximum system interoperability. The link control interfaces to the integrated transceivers.

### 3.3.5 High-Speed Link Adaptive Equaliser and Cable Driver on Copper Media

The CCPMC Adapter integrates a High-Speed link adaptive equaliser and cable driver between the IOCs internal transceivers and the backplane I/O. The cable driver (transmission) output is implemented by using Current-Mode Logic (CML). The maximum output amplitude can be adjusted over a range of typically 450 mV to 870 mV. The adaptive cable equaliser (receiver) automatically adjusts to attenuation levels of up to 30 dB at 1,6 GHz (due to skin effect losses in copper cable). The equaliser consists of a CML input buffer, a loss-of-signal detector, a flat response amplifier, a skin-effect compensation amplifier, a current-steering network, a dual power-detector feedback loop, an output limiting amplifier and a CML output buffer.

This feature ensures signal integrity and adds additional protection to the IOC.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 6 of 16

4. Connector Pin Assignments

This section shows the various connector pin assignments for connecting the FC Adapter to the host and other targets.

4.1 PMC Connector Pinouts

Figure 2 shows the layout of the PMC connectors on the PMC Adapter.

Refer to the PMC draft [Par. 2.2.2] for a detailed description of the PMC pinouts.




Figure 2 : PMC Connector Layout on FC PMC Adapter

4.2 Indicators




Figure 3 : LED Layout on CCPMC and PMC Adapters

## 5. Hardware Installation

This section will describe the installation procedure for installing the FC Adapter on a Host Carrier Card (HCC).

### 5.1 The Adapter Kit


The adapter kit consists of the following items :

- Cardboard Package
- Electrostatic Discharge (ESD) Protective Bag
- The Adapter
- A Paper Envelope containing an Installation Diskette
- PMC Fasteners
- CD containing User Manuals, Installation Guides and Drivers

If any item is missing or damaged, contact C<sup>2</sup>I<sup>2</sup> Systems.

Please refer to the Release Notes on the diskette for the latest information regarding this product.

### 5.2 Handling Instructions

Attention: ESD can damage the Adapter	
	Do not open the ESD protective package containing the adapter until you are prompted to do so.
	Follow strict ESD handling procedures. Failure to do so may result in damage to the adapter.
	Use must be made of an ESD station and grounding wrist strap when handling the Adapter.

### 5.3 Installation of the Adapter

The installation of the FC Adapter will be illustrated in the following steps. Note that the installation done here was done on arbitrary HCC's to demonstrate the basic steps of installing a CCPMC or PMC Adapter on an HCC.

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 8 of 16

### 5.3.1 Step 1 - Prepare the Host Carrier Card (HCC)

Observe all the relevant ESD precautions and remove the HCC from it's ESD protective bag and place HCC on an ESD workstation.




Figure 4 : HCC placed on an ESD Workstation

### 5.3.2 Step 2 - Install the Adapter onto Host Carrier Card

Remove the FC Adapter from the protective bag and install the adapter as shown in the figures below. The installation of the PMC Adapter is illustrated in Figure 5.




Figure 5 : Fitting Frontpanel I/O Transceivers Through Frame of the HCC

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 9 of 16



In case of the CCPMC Adapter, the Adapter simply fits onto the HCC as shown below.




Figure 6 : Installing the CCPMC on HCC

Be sure to align the female PMC connectors on the FC Adapter with the male PMC connectors on the HCC before pressing down on the FC Adapter.

Figure 9 shows the PMC Adapter installed on a HCC.




Figure 7 : Correctly Align the PMC Connectors

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 10 of 16




Figure 8 : The FC Adapter Installed on HCC with PMC Connectors Connected

### 5.3.3 Step 3 - Securing the FC Adapter



Figure 9 : A PMC Adapter Installed on a HCC

There are three types of screws that may be required to secure the FC Adapter to an HCC. The types are listed in the table below :

Name	Size
Cheese Head	M2 X 6
Cheese Head	M2.5 X 5
Countersunk	M2.5 X 6

Table 3 : Types of Securing Screws

The specific screws required from the above table depends on the HCC used.

#### 5.3.3.1 Securing the PMC Adapter

The PMC Adapter is secured from the bottom side of the HCC. Four screws are used, two to secure the bezel and two to secure the standoffs. This is illustrated in Figure 10 and Figure 11.






Figure 10 : Securing the Bezel




Figure 11 : Securing the Standoffs onto the HCC

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 12 of 16



### 5.3.3.2 Securing the CCPMC Adapter

The CCPMC Adapter must be secured to the thermal conduction ribs of the HCC and from the reverse side at the standoffs of the FC Adapter.




Figure 12 : Secured CCPMC Adapter on the Thermal Conduction Ribs of the HCC




Figure 13 : CCPMC Adapter Secured at Standoffs from the Reverse Side of HCC

CCII/FC/6-MAN/003	2009-08-20	Issue 1.3
CFCMAN03.WPD		Page 13 of 16

6. **CCPMC Adapter J4 Pinout Assignment**

Signal Name	Pn4 Pin No.	DY4 SVME/DMV 18x Pin Mapping	
		P0 Pin No. (Site 1)	P2 Pin No. (Site 2)
Channel B RX -	1	E4	C1
Channel B TX -	2	D4	A1
Channel B RX +	3	C4	C2
Channel B TX +	4	B4	A2
Signal Ground	5	A4	C3
Signal Ground	6	E5	A3
LED0	7	D5	C4
LED4	8	C5	A4
LED1	9	B5	C5
GPIO0	10	A5	A5
LED2	11	E6	C6
GPIO1	12	D6	A6
LED3	13	C6	C7
GPIO2	14	B6	A7
Fused 5 V	15	A6	C8
Fused 5 V	16	E7	A8
	17	D7	C9
	18	C7	A9
	19	B7	C10
	20	A7	A10
	21	E8	C11
	22	D8	A11
	23	C8	C12
	24	B8	A12
	25	A8	C13
	26	E12	A13
	27	D12	C14
	28	C12	A14
	29	B12	C15
	30	A12	A15
	31	E13	C16
	32	D13	A16
	33	C13	C17
	34	B13	A17
	35	A13	C18
	36	E14	A18
	37	D14	C19
	38	C14	A19
	39	B14	C20
	40	A14	A20
	41	E15	C21
	42	D15	A21
	43	C15	C22
	44	B15	A22
	45	A15	C23
	46	E16	A23
	47	D16	C24
	48	C16	A24
	49	B16	C25
	50	A16	A25
	51	E17	C26
	52	D17	A26
	53	C17	C27
	54	B17	A27
	55	A17	C28
	56	E18	A28
	57	D18	C29
	58	C18	A29
Signal Ground	59	B18	C30
Signal Ground	60	A18	A30
Channel A TX -	61	E19	C31
Channel A RX -	62	D19	A31
Channel A TX +	63	C19	C32
Channel A RX +	64	B19	A32



## Annexure A Specifications

Designation	I/O Connector	Grade	Media	Speed
CCII/FC/PMC/2P/FP/COM	Dual SFF	Commercial	Multimode Fibre	2 Gbit/s
CCII/FC/PMC/2P/FP/IND	Dual SFF	Industrial	Multimode Fibre	2 Gbit/s
CCII/FC/PMC/BP/CC	PMC Jn4 (Dual)	CC	Copper	1 Gbit/s
PMC Interface	Bus Address Bus Compliance Interrupts Address Cycle Data Transfer	PnP auto selected 64-bit, 66 MHz, backward compatible with 32-bit, 33 MHz PCI Rev. 2.2 PCI INT A + B Dual Address Cycle Support Bus Mastering and Scatter Gather		
Dimensions	Single CMC IEEE P1386 compliant (149 mm x 74 mm x 9,8 mm)			
Mass	80 g ± 10 g			
Power Requirements	+5 V 0,9 A (copper) +5 V 1,0 A (fibre) +5 V 1,5 A (max)			
MTBF	Figures according to MIL-HDBK-217F, Parts Count Method:			
	Ground Mobile	T <sub>j</sub> = 65 C	T <sub>a</sub> = 45 C	17 000 hrs
	Naval, Sheltered	T <sub>j</sub> = 65 C	T <sub>a</sub> = 40 C	23 000 hrs
	Airborne, Inhabited Cargo	T <sub>j</sub> = 75 C	T <sub>a</sub> = 55 C	17 000 hrs
Environmental Specifications	Temperature Operating Temp. Storage Temp.	Commercial 0 C to +55 C -40 C to +85 C	Industrial -15 C to +75 C -40 C to +85 C	CC -40 C to +85 C -55 C to +125 C
	Humidity	0 - 90%	0 - 95%	0 - 95%
	Shock	N/A	30 g peak half sine 11 ms	40 g peak half sine 11 ms
	Random Vibration	N/A	0,04 g <sup>2</sup> /Hz 15 to 2 kHz	0,1 g <sup>2</sup> /Hz 15 to 2 kHz
Software Drivers	<ul style="list-style-type: none"><li>• VxWorks</li><li>• Windows NT4/Windows 2000</li><li>• Linux</li></ul>			
Protocols	FC/Internet (singular or intermixed) :  <ul style="list-style-type: none"><li>• TCP/IP</li><li>• SCSI</li></ul> Custom Protocols supported (singular or intermixed).			